

MODEL: My SmartBike Active Charger

Nominal voltage AC: **90-246 , 50-60 Hz**

Dimensions: **187 x 90 x 44.4 mm (Length x Width x Height)**

Nominal voltage CA: **42 v - 2.1 A / 4 A**

Ingress protection: **IP54**


Voltage and charging voltage CC: **42v 2.1A / 4A**

Weight: **689 grs**

Ambient temperature: **90 °C / -15 °C**

8 Light signals / Light signals

<p>White light Steady light</p> 	<p>EN Standby ES Standby DE Standby FR Standby</p>	<p>IT Standby PT Standby NL Standby KR Standby</p>	<p>Blue light Breathing effect</p> 	<p>EN Charging ES Charging DE Charging FR Charging</p>	<p>IT Charging PT Charging NL Charging KR Charging</p>
<p>Green light Steady light</p> 	<p>EN Charge completed ES Charge completed DE Charge completed FR Charge completed</p>	<p>IT Charge completed PT Charge completed NL Charge completed KR Charge completed</p>	<p>Red light Constant blinking</p> 	<p>EN Error ES Error DE Error FR Error</p>	<p>IT Error PT Error NL Error KR Error</p>
<p>Blue light Steady light</p> 	<p>EN Connected to USB & ready. ES Connected to USB & ready. DE Connected to USB & ready. FR Connected to USB & ready.</p>	<p>IT Connected to USB & ready. PT Connected to USB & ready. NL Connected to USB & ready. KR Connected to USB & ready.</p>	<p>Purple light Constant blinking</p> 	<p>EN Updating ES Updating DE Updating FR Updating</p>	<p>IT Updating PT Updating NL Updating KR Updating</p>
<p>Red light Steady light</p> 	<p>EN Connected to USB without power ES Connected to USB without power DE Connected to USB without power FR Connected to USB without power</p>	<p>IT Connected to USB without power PT Connected to USB without power NL Connected to USB without power KR Connected to USB without power</p>	<p>Purple to green light</p> <p>EN Updating complete ES Updating complete DE Updating complete</p>	<p>FR Updating complete IT Updating complete PT Updating complete NL Updating complete KR Updating complete</p>	<p>Purple to red light</p> <p>EN Updating error ES Updating error DE Updating error</p>



- EN** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.
- FR** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.
- N** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.

- ES** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.
- IT** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.
- KR** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.

- DE** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.
- PT** - Keep battery charged around 50% (between 40%-70%) when long term storage.
- Use only indoors.
- Work temperatures between 10 °C and 40 °C
- Do not submerge or expose to water.

9 Trouble shooting / Trouble shooting

EN	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

DE	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

IT	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

NL	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

ES	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

FR	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

PT	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

KR	Warning Light	Cause	Solution
	No light	Charger power error	Check that charger, its wire and the socket from the installation are in good condition. Make sure your power supply is working and its tension is compatible with the working values of charger.
	Blinking red	Charger error	Connect to your eBike through My SmartBike App to know the error and its solution.
	Blinking white when connected to eBike	Communication error between charger and eBike	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady white when connected to eBike	Charger error	Check the connection between charger and eBike. Check the status of all connectors and make sure there is no damage or humidity.
	Steady red when connected through micro-USB	Micro-USB is not active	Check that charger is connected to an active computer. If not, disconnect the wire from the micro-USB.

10 Legal advice / Legal advice

EN Hereby, MAHLE Smartbike Systems S.L.U. declares that the My SmartBike Active Charger complies directive 2014/35/EU (LVD) and the Harmonized Standard of reference, including all its reference standards mentioned therein and applicable to this product: EN 15194:2017. This document is written in English language and the content of which shall prevail in the event of any translation error or misunderstanding in its interpretation by the client.

DE Hereby, MAHLE Smartbike Systems S.L.U. declares that the My SmartBike Active Charger complies directive 2014/35/EU (LVD) and the Harmonized Standard of reference, including all its reference standards mentioned therein and applicable to this product: EN 15194:2017. This document is written in English language and the content of which shall prevail in the event of any translation error or misunderstanding in its interpretation by the client.

FR Hereby, MAHLE Smartbike Systems S.L.U. declares that the My SmartBike Active Charger complies directive 2014/35/EU (LVD) and the Harmonized Standard of reference, including all its reference standards mentioned therein and applicable to this product: EN 15194:2017. This document is written in English language and the content of which shall prevail in the event of any translation error or misunderstanding in its interpretation by the client.

NL Hereby, MAHLE Smartbike Systems S.L.U. declares that the My SmartBike Active Charger complies directive 2014/35/EU (LVD) and the Harmonized Standard of reference, including all its reference standards mentioned therein and applicable to this product: EN 15194:2017. This document is written in English language and the content of which shall prevail in the event of any translation error or misunderstanding in its interpretation by the client.

KR Hereby, MAHLE Smartbike Systems S.L.U. declares that the My SmartBike Active Charger complies directive 2014/35/EU (LVD) and the Harmonized Standard of reference, including all its reference standards mentioned therein and applicable to this product: EN 15194:2017. This document is written in English language and the content of which shall prevail in the event of any translation error or misunderstanding in its interpretation by the client.